

## Common Connector Combinations

			
<b>UHF M – UHF M</b>	<b>UHF F – UHF F</b>	<b>UHF Bulkhead</b>	<b>UHF F – UHF M Elbow</b>
			
<b>UHF M – SMA M</b>	<b>UHF M – SMA F</b>	<b>UHF F – SMA M</b>	<b>UHF F – SMA F</b>
			
<b>BNC F – SMA M</b>	<b>UHF M – BNC M</b>	<b>UHF F – BNC M</b>	<b>BNC M – SMA F</b>
			
<b>UHF M – BNF F</b>	<b>UHF F – BNC F</b>	<b>BNC F – SMA F</b>	<b>BNC M – BNC M</b>
			
<b>BNC F – BNC F</b>	<b>NMO M – UHF F</b>	<b>UHF F – NMO F</b>	<b>UHF M – N F</b>
			
<b>N M – N M Elbow</b>	<b>N M – N F Elbow</b>	<b>N F – N F</b>	<b>N M – N M</b>

UHF Male is also specified as PL-259 (PL as in plug) – UHF Female is also specified as SO-239 (SO as in socket)